



Tecnologie per IoT

Daniele Jahier Pagliari

Lab1: Hardware





PART2: EXERCISE 1



Exercise 1

- Read specification on the lab PDF...
 - Some further details here



Exercise 1

- Spec. 1)
 - To reduce the number of wires and connections, you can also use the internal temperature sensor of the Arduino...
 - Although less precise and accurate than the external one.



Parenthesis: LSM6DSOXTR

- The board includes a LSM6DSOXTR Inertial Measurement Unit (IMU) from STM.
 - 3D Accelerometer + 3D Gyroscope + Temperature Sensor
- We can use the IMU functionality by including the corresponding library:

```
1  #include <Arduino_LSM6DSOX.h>
```



Parenthesis: LSM6DSOXTR

- In the setup() we must initialize the library as follows:

```
7   if (!IMU.begin()) {  
8       Serial.println("Failed to initialize IMU!");  
9       while(1);  
10  }
```

- Lastly, we can read the temperature (directly in Celsius, as an int) with the following code:
 - Drawback: the resolution is 1 degree, and the sensor less accurate than the external one.

```
14   if (IMU.temperatureAvailable()) {  
15       int temperature = 0;  
16       IMU.readTemperature(temperature);  
17   }
```



Exercise 1

- Spec. 2)
 - LED light is proportional to current
 - With the circuit of Ex. 1.1, we can regulate the current by reducing the voltage drop
 - **We can control LED intensity using PWM!**




Exercise 1

- Spec. 4)
 - We didn't look at the microphone yet...



Microphone

- The RP2040 Connect has an on-board MP35DT05 microphone that uses PDM (Pulse-Density Modulation)
 - PDM is a more general case of PWM with variable period.
 - [Datasheet](#).





Microphone

- Luckily the PDM arduino library does the PDM-to-digital conversion for you
- You should use this library to interact with the microphone
- Include the header file:

```
1 #include <PDM.h>
```

- In the globals, define a buffer to store the audio samples (converted to 16bit digital values). By default, the library expects a 512 bytes buffer. This can be changed with (setBufferSize()):

```
14 // Buffer to read samples into, each sample is 16-bits  
15 volatile short sampleBuffer[256];
```



Microphone

- In the setup(), associate a callback to execute everytime new data arrives

Callback function (ISR)

```
22 PDM.onReceive(onPDMdata);
```

- Then initialize the PDM sensor:

N. Channels (1 = mono) Sample frequency

```
23 if (!PDM.begin(1, 16000)) {  
24     Serial.println("Failed to start PDM!");  
25     while (1);  
26 }
```



Microphone

- ISR function:
 - Check how many bytes are available
 - Read them in the buffer
 - Remember that each sample requires 2 bytes
 - Note: it's an ISR, so you can't call `delay()`, `Serial.print()`, etc.

```
64 void onPDMdata() {  
65     // Query the number of available bytes  
66     int bytesAvailable = PDM.available();  
67     // Read into the sample buffer  
68     PDM.read(sampleBuffer, bytesAvailable);  
69     // 16-bit, 2 bytes per sample  
70     samplesRead = bytesAvailable / 2;  
71 }
```



Microphone

- In the loop(), use the buffer values as needed...

```
63 void loop() {  
64     if (samplesRead) {  
65         for (int i = 0; i < samplesRead; i++) {  
66             Serial.println(sampleBuffer[i]);  
67         }  
68         samplesRead = 0;  
69     }  
70 }
```

- Note: this is an example, implementing the lab request is more tricky!!



Exercise 1

- Spec. 6)
 - When presence is detected:
 - $T_{AC,min} = T_{AC,min,pres}$
 - $T_{AC,max} = T_{AC,max,pres}$
 - etc. (same for heater)
 - Otherwise:
 - $T_{AC,min} = T_{AC,min,abs}$
 - $T_{AC,max} = T_{AC,max,abs}$
 - etc. (same for heater)



Exercise 1

- The rest is up to you...